


DIY CORNHOLE


Board Plans

These plans are built to the official cornhole board standards. These plans make two boards.

Board Cut Diagram



Plywood Cut Diagram



Tools:

- Miter Saw or Circular Saw
- Pencil
- Jig Saw
- Table Saw
- 3/8" Drill Bit
- Drill
- Hammer
- Compass
- Measuring Tape
- Clamps

Materials List:

Material	Quantity
2 x 4 x 8'	4 Boards
1/2" X 4' x 8' Plywood	1 Sheets
2-1/2" Wood Screws	32
1-1/2" Wood Screws	20
4" long x 3/8" carriage bolts	4
3/8" Washers	4
3/8" Wing Nuts	4
Exterior Finish	1 Small Can

Build Instructions:

1. Start by trimming off the rough end of the 2 x 4 boards with your miter saw.
2. Follow the cut diagram for the producing all the pieces required.
3. Start by assembling the frame and attach the top once that is complete.
4. Use your compass to draw a 6" diameter hole as indicated on the cut diagram. Use your jigsaw to make the circular cut.
5. Attach the legs with the carriage bolts, washers, and wing nuts. Then screw the crosspiece between the legs.
6. Finish the top with an exterior finish and repeat these steps for the second board.